

**Aftermarket Non-Genuine Replacement  
Spare Parts For Ingersoll Rand Air Compressor  
Model : Type 30, ESV, ESH, PHE, IHE, XLE-Lub & Non-Lub**



**AN ISO 9001 : 2008 CERTIFIED CO.**

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time , the illustration and specifications are subject to change without notice.

**Aftermarket Non-Genuine Replacement Spare Parts For Ingersoll Rand Air Compressor  
Type 30 Model**

**Single & Two Stage Air Compressor**

242, 234, 253, 71T2

15T, 30T, 25T2

2340, 2475, 2540, 2545

7100, 3000

**Multi Stage High Pressure Air Compressor**

231, 7T2, 15T2

**Single & Two Stage Vacuum Pump**

7V, V235, V244, V255

7VT, V235T, V244T, V255T



Crankshaft I Connecting Rod I Bushes I Service Kit I Valve Assembly I Cylinder I Gasket Kit I Piston I Air Filter Element I Intercooler Tube I Oil Seal I Ring Set I Valve Gasket Kit I Bearing / Connecting Rod Kit I Ring Gasket Kit I Spacer Plate I Stop Plate I Tune up Kit I Flywheel I Piston Assembly I Check Valve I Crankpin Bushing I Safety Valve I Valve Damper I Valve Seat I Pilot Valve I Finger Valve I Crankcase.

**Aftermarket Non-Genuine Replacement Spare Parts For Ingersoll Rand Air Compressor  
Model : ESV, ESH, PHE, IHE - Lubricated & Non Lubricated**

**ESV & ESH Models – Lub & Non-Lub**

7 x 5, 8 x 5, 9.5 x 5,  
8 x 7, 9.5 x 7, 11 x 7,

**PHE – Lub & Non-Lub**

10 & 5 x 7, 12 & 5 x 7, 12 & 7 x 7,  
16 & 10 x 7,  
14 & 6 x 9, 17 & 9 x 9, 17 & 9 & 4.5 x 9,  
12 & 5 & 4 x 7, 12 & 7 & 5 x 7,

**IHE – Lub & Non-Lub**

12 & 6.5 x 7 IHE -2 NL2,  
12 & 7 x 7 IHE-5 NL,  
12 & 12 x 7 IHE-NL,  
16 & 9B x 7 2IHE-2NL-2,



Valve Assembly | Crankshaft | Port Plate | Valve | Piston Ring Unloader | Oil Pump | Ring & Spring | Connecting Rod | Channel & Spring Set | Valve Seat | Stop Plate Inlet | Plate Seat | Holder guide | Crab Discharge | Discharge Valve | Inlet Valve | FAU Complete | Unloader Cage | Unloader Plunger | Piston Ring | Wearing Ring | Scraper Ring | Packing Ring | Seat Valve | Wear Strip | Balance Flow.



**Aftermarket Non-Genuine Replacement Spare Parts For Ingersoll Rand Air Compressor  
Model : XLE - Lubricated & Non Lubricated**



**XLE Models – Lub & Non-Lub**

14 1/2" - 9" x 7", 16" - 9" x 7",  
16" - 10" x 7", 17" - 10" x 7",  
18 1/2" - 11 1/2" x 8 1/2",  
19" - 11 1/2" x 8 1/2",  
20 1/2" - 11 1/2" x 8 1/2",  
20 1/2" - 12 1/2" x 8 1/2",  
21 1/2" - 12 1/2" x 8 1/2",  
22" - 13 1/2" x 10",  
24 1/4" - 13 1/2" x 10",  
24 1/4" - 14 1/2" x 10",  
25" - 14 1/2" x 10",  
26" - 14 1/4" x 10",  
28" - 16" x 10" XLE-2,

Cylinder Head | Cylinder | Connecting Rod | Piston Rod | Cross Head | Port Plate | Discharge Valve | Inlet Valve | FAU Complete | Valve Cover | Unloader Cage | Unloader Plunger | Piston Ring | Wearing Ring | Scrapper Ring | Packing Ring | Seat Valve Inlet | Wear Strip | Balance Flow.

All manufacturer's names, numbers, photos, product description and/or part numbers are used for reference purposes only & it is not implied that any part listed is the product of these manufacturers. Since Approvement are made from time to time , the illustration and specifications are subject to change without notice.

Division of :

**Vikay Mining Equipments**

2/5 Vyas Wadi, Dadabhai Road, Vile Parle (West), Mumbai - 400 056. INDIA.

Tel. : +91 - 22 - 2623 7205 / 2624 3729 Fax : +91 - 22 - 2671 6507 / 2671 9985

Email : vkmining@vsnl.com / vkmining@gmail.com

Website : [www.partsforcompressor.com](http://www.partsforcompressor.com)

